



PROVIDE COLUMN AS INDICATED

Provide THE COLUMN AS INDICATED FROM SF TO T.FLOOR

PROVIDE COLUMN AS INDICATED FROM SECOND FLOOR

RESTRICT COLUMN SIZE AS INDICATED FROM SF TO THIRD FLOOR

ALIGN THE COLUMN AS PER PLAN

SECOND FLOOR SHUTTERING LAYOUT
(SCALE 1:75)

STAIRCASE NOT MATCHING TO PLAN